

Product Group: SG2 Programmable Relay
Number: AN-SG2-024

Date Issued: 11/1/2017
Revision: Original

Title: SG2 PLR Program and *iView* HMI Program for RS232 Communication

Summary: This application note will show how to set the programming for the operation of the SG2 PLR and *iView* HMI once they are connected using the RS232 communication port. For this application note, we will be using the SG2-10HR-A, the *iView* IV07M-SEAP, the SG2-PL01 cable and the SMTIV-RS232 cable.

SG2-10HR-A Program:

Step 1: Select “New Ladder Logic Program” and then select “SG2-10HR-A” for model type.




Figure 1




Figure 2

Step 2: Create an SG2 test program that will use an internal coil closing an external output. Place M01 contact in the first column of row 1 and run a power line to the second-to-last column. Place Q01 coil in last column as shown in Figure 3.



Figure 3

When the M01 contact is active, the Q01 output will be active.

Step 3: Now write the program to the SG2.

Information herein is provided by FactoryMation Technical Support “as is” with no guarantee of any kind. Customer is solely responsible for validating application, operation, maintenance, and code compliance and other information and data relating to the installation, operation, safety and maintenance of all components. FactoryMation does not guarantee that this information is suitable for your application, nor does FactoryMation assume any responsibility for your product design, installation, testing, or operation.



For further instruction on programming and how to upload a program to the SG2, please refer to the FactoryMation Knowledge Base, Programmable Controllers, <http://www.factorymation.com/topic/10>.

iView HMI Program:

Step 1: Open a new program under “New Project” and name it. Then select “Next”.




Figure 4

Step 2: Enter application name and HMI screen information and then select “Next”.




Figure 5

Information herein is provided by FactoryMation Technical Support “as is” with no guarantee of any kind. Customer is solely responsible for validating application, operation, maintenance, and code compliance and other information and data relating to the installation, operation, safety and maintenance of all components. FactoryMation does not guarantee that this information is suitable for your application, nor does FactoryMation assume any responsibility for your product design, installation, testing, or operation.

Step 3: Set Device to “TECO Electric & Machinery Co. Ltd.” and set Server to “SG2 V3 RS232 Protocol”, then select “Next”.




Figure 6



If the Server is set to anything other than “SG2 V3 RS232 Protocol” the HMI will NOT be able to communicate to the SG2 using the RS-232 communication port.

Step 4: Set Link Parameters as follows to complete New Project set-up.

- 4.1 Baud Rate: 19200
- 4.2 Data Bits: 8
- 4.3 Parity: None
- 4.4 Stop Bits: 1
- 4.5 Panel Address: 1
- 4.6 PLC Address: 1
- 4.7 Timeout Time: 10
- 4.8 Command Delay: 10
- 4.9 Retry Count: 3




Figure 7

Information herein is provided by FactoryMation Technical Support “as is” with no guarantee of any kind. Customer is solely responsible for validating application, operation, maintenance, and code compliance and other information and data relating to the installation, operation, safety and maintenance of all components. FactoryMation does not guarantee that this information is suitable for your application, nor does FactoryMation assume any responsibility for your product design, installation, testing, or operation.

Step 5: Now the screen is ready to be programmed for testing. Select “Toggle Switch” to correspond to the M01 contact in the SG2 program.




Figure 8

Step 6: Place Toggle Switch element onto HMI screen. Then double-click the element to open the programming window.




Figure 9

Information herein is provided by FactoryMation Technical Support “as is” with no guarantee of any kind. Customer is solely responsible for validating application, operation, maintenance, and code compliance and other information and data relating to the installation, operation, safety and maintenance of all components. FactoryMation does not guarantee that this information is suitable for your application, nor does FactoryMation assume any responsibility for your product design, installation, testing, or operation.

Step 7: Assign the “Write Address” to correspond to the M01 contact in the SG2 program.




Figure 10



For this application, the Toggle Switch will appear as a green button in the “Off” state and a red button in the “On” state.




Figure 11

Information herein is provided by FactoryMation Technical Support “as is” with no guarantee of any kind. Customer is solely responsible for validating application, operation, maintenance, and code compliance and other information and data relating to the installation, operation, safety and maintenance of all components. FactoryMation does not guarantee that this information is suitable for your application, nor does FactoryMation assume any responsibility for your product design, installation, testing, or operation.

Step 8: Now place a Bit Lamp to indicate the Q01 output state.



Figure 12

Step 9: Place the Bit Lamp element onto the HMI screen. Then double-click the element to open a programming window.




Figure 13

Information herein is provided by FactoryMation Technical Support "as is" with no guarantee of any kind. Customer is solely responsible for validating application, operation, maintenance, and code compliance and other information and data relating to the installation, operation, safety and maintenance of all components. FactoryMation does not guarantee that this information is suitable for your application, nor does FactoryMation assume any responsibility for your product design, installation, testing, or operation.

Step 10: Assign the “Write Address” to correspond to the Q01 output in the SG2 program.




Figure 14



For this application, the Bit lamp is a round indicator that will turn Green when the Q01 output is active.

Step 11: Compile program and then download program to the HMI screen. Figure 15 shows the HMI screen when M01 contact is not active:




Figure 15

Information herein is provided by FactoryMation Technical Support “as is” with no guarantee of any kind. Customer is solely responsible for validating application, operation, maintenance, and code compliance and other information and data relating to the installation, operation, safety and maintenance of all components. FactoryMation does not guarantee that this information is suitable for your application, nor does FactoryMation assume any responsibility for your product design, installation, testing, or operation.

Figure 16 shows the HMI screen when M01 is active:




Figure 16



See Application Note AN-HMI-018 on how to connect SG2-10HR-A to *iView* HMI using the IMO SMTIV-RS232 and SG2-PL01 for RS232 communication.

You are now ready to complete your SG2 and *iView* programming as desired for your application needs.

Information herein is provided by FactoryMation Technical Support "as is" with no guarantee of any kind. Customer is solely responsible for validating application, operation, maintenance, and code compliance and other information and data relating to the installation, operation, safety and maintenance of all components. FactoryMation does not guarantee that this information is suitable for your application, nor does FactoryMation assume any responsibility for your product design, installation, testing, or operation.